Alcotest 7110 Calibration Record

Equipment Alcotest 7110 MKIII-C Serial No.: ARWF-0382

Location: WEST WINDSOR POLICE

Calibration File No.: 01471 Calib. Date: 12/04/2017 Calib. No.: 00042 Certification File No.: 01446 Cert. Date: 07/26/2017 Cert. No.: 00028 Linearity File No.: Lin. Date: 01447 07/26/2017 Lin. No.: 00027 Solution File No.: 01470 Soln. Date: 11/14/2017 Soln. No.: 00224

Sequential File No.: 01471 File Date: 12/04/2017

Calibrating Unit: WET Model No.: CU-34 Serial No.: DDWJ S3-0363 Control Solution %: 0.100% Expires: 10/10/2018

Solution Control Lot: 16270 Bottle No.: 0523

Coordinator

Last Name: GONCALVES First Name: MICHELLE MI: L

ignature: # 6040 Badge No.: 6040 Date: 12/04/2017

*Black Key Temperature Probe Serial.....# DDXKP2 - 398 Wa

*Digital NIST Temperature Measuring System Serial.....# 17 03 09355 (MC)

Pursuant to law, and the "Chemical Breath Testing Regulations" N.J.A.C. 13:51, I am a duly appointed Breath Test Coordinator/Instructor. In my official capacity, and consistent with "Calibration Check Procedure for Alcotest 7110," as established by the Chief Forensic Scientist of the Division of State Police, I perform calibration checks on approved instruments employing infrared analysis and electrochemical analysis, when utilized in a single approved instrument as a dual system of chemical breath testing. Pursuant to, and consistent with, the current "Calibration Check Procedure for Alcotest 7110," as established by the Chief Forensic Scientist, I performed a Calibration Check on the approved instrument identified on this certificate. The results of my Calibration Check are recorded on this certificate, which consists of two parts on two pages: Part I - Control Tests; and Part II - Linearity Tests. I certify that the foregoing statements made by me are true. I am aware that if any of the foregoing statements made by me are wilfully false, I am subject to punishment.

Alcotest 7110 Calibration Certificate

Part I - Control Tests

Equipment Location:	Alcotest 7110 MKIII-C WEST WINDSOR POLIC	Œ		Serial No.: ARWF-0382
Calibration File No.:	01471	Calib. Date	: 12/04/2017	Calib. No.: 00042
Certification File No.:	01472	Cert. Date:	12/04/2017	Cert. No.: 00029
Linearity File No.:	01447	Lin. Date:	07/26/2017	Lin. No.: 00027
Solution File No.:	01470	Soln. Date:	11/14/2017	Soln. No.: 00224
Sequential File No.:	01472	File Date:	12/04/2017	
Calibrating Unit:	WET	Model No.	: CU-34	Serial No.: DDWJ S3-0363
Control Solution %:	0.100%			Expires: 10/10/2018
Solution Control Lot:	16270			Bottle No.: 0523
Function	Result	Time	Temperature	Comment(s)
	%BAC	HH:MM	Simulator (°C)	or Error(s)
Ambient Air Blank	0.000%	10:34S		
Control 1 EC	0.099%	10:35S	34.0°C	*** TEST PASSED ***
Control 1 IR	0.099%	10:35S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	10:36S		
Control 2 EC	0.099%	10:36S	34.0°C	*** TEST PASSED ***
Control 2 IR	0.099%	10:36S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	10:37S		
Control 3 EC	0.099%	10:38S	34.0°C	*** TEST PASSED ***
Control 3 IR	0.099%	10:38S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	10:38S		

All tests within acceptable tolerance.

Coordinator

Last Name: GONCALVES

First Name: MICHELLE

MI: L

Signature:

Ln#6040

Badge No.: 6040

Date: 12/04/2017

Pursuant to law, and the "Chemical Breath Testing Regulations" N.J.A.C. 13:51, I am a duly appointed Breath Test Coordinator/Instructor. In my official capacity, and consistent with "Calibration Check Procedure for Alcotest 7110," as established by the Chief Forensic Scientist of the Division of State Police, I perform calibration checks on approved instruments employing infrared analysis and electrochemical analysis, when utilized in a single approved instrument as a dual system of chemical breath testing. Pursuant to, and consistent with, the current "Calibration Check Procedure for Alcotest 7110," as established by the Chief Forensic Scientist, I performed a Calibration Check on the approved instrument identified on this certificate. The results of my Calibration Check are recorded on this certificate, which consists of two parts on two pages: Part I - Control Tests; and Part II - Linearity Tests. I certify that the foregoing statements made by me are true. I am aware that if any of the foregoing statements made by me are wilfully false, I am subject to punishment.

Alcotest 7110 Calibration Certificate

Part II - Linearity Tests

Equipment Location:	Alcotest 7110 M WEST WINDS				Serial No.:	ARWF-0382
Calibration File No.:	01471		Calib. Date:	12/04/2017	Calib. No.:	00042
Certification File No.:			Cert. Date:	12/04/2017	Cert. No.:	00029
Linearity File No.:	01473		Lin. Date:	12/04/2017	Lin. No.:	00028
Solution File No.:	01470		Soln. Date:	11/14/2017	Soln. No.:	00224
Sequential File No.:	01473		File Date:	12/04/2017		
Calibrating Unit:	WET		Model No.:	CU-34		DDRK S3-0012
Control Solution %:	0.040%				Expires:	09/19/2018
Solution Control Lot:	16230				Bottle No.:	0841
Calibrating Unit:	WET		Model No.:	CU-34		DDRK \$3-0015
Control Solution %:	0.080%				Expires:	09/27/2018
Solution Control Lot:	16250				Bottle No.:	0302
Calibrating Unit:	WET		Model No.:	CU-34		DDRK \$3-0025
Control Solution %:	0.160%				Expires:	10/03/2018
Solution Control Lot:	16260				Bottle No.:	0382
Function		Result	Time	Temperature		ment(s)
4 11 / 41 751 1		%BAC	HH:MM	Simulator (°C)	or Er	ror(s)
Ambient Air Blank		0.000%	10:49S	0.4.00.0		
Control 1 EC		0.041%	10:50S	34.0°C		PASSED ***
Control 1 IR		0.038%	10:50S	34.0°C	*** TEST I	PASSED ***
Ambient Air Blank		0.000%	10:51S 10:52S	2.4.00.0	delete manage v	
Control 2 EC		0.041%	10:528	4/1 Mol .		
Control 2 IR Ambient Air Blank		0.000		34.0°C		PASSED ***
Ambieni Air biank		0.039%	10:52S	34.0°C		PASSED *** PASSED ***
		0.000%	10:52S 10:53S	34.0°C	*** TEST I	PASSED ***
Control 3 EC		0.000% 0.081%	10:52S 10:53S 10:54S	34.0°C 34.0°C	*** TEST I	PASSED *** PASSED ***
Control 3 EC Control 3 IR		0.000% 0.081% 0.079%	10:52S 10:53S 10:54S 10:54S	34.0°C	*** TEST I	PASSED ***
Control 3 EC Control 3 IR Ambient Air Blank		0.000% 0.081% 0.079% 0.000%	10:52S 10:53S 10:54S 10:54S 10:56S	34.0°C 34.0°C 34.0°C	*** TEST I *** TEST I *** TEST I	PASSED *** PASSED *** PASSED ***
Control 3 EC Control 3 IR Ambient Air Blank Control 4 EC		0.000% 0.081% 0.079% 0.000% 0.080%	10:528 10:538 10:548 10:548 10:568 10:568	34.0°C 34.0°C 34.0°C	*** TEST I *** TEST I *** TEST I	PASSED *** PASSED *** PASSED ***
Control 3 EC Control 3 IR Ambient Air Blank Control 4 EC Control 4 IR		0.000% 0.081% 0.079% 0.000% 0.080% 0.079%	10:528 10:538 10:548 10:548 10:568 10:568 10:568	34.0°C 34.0°C 34.0°C	*** TEST I *** TEST I *** TEST I	PASSED *** PASSED *** PASSED ***
Control 3 EC Control 3 IR Ambient Air Blank Control 4 EC Control 4 IR Ambient Air Blank		0.000% 0.081% 0.079% 0.000% 0.080% 0.079% 0.000%	10:52S 10:53S 10:54S 10:54S 10:56S 10:56S 10:56S 10:58S	34.0°C 34.0°C 34.0°C 34.0°C 34.0°C	*** TEST I *** TEST I *** TEST I *** TEST I	PASSED *** PASSED *** PASSED *** PASSED ***
Control 3 EC Control 3 IR Ambient Air Blank Control 4 EC Control 4 IR Ambient Air Blank Control 5 EC		0.000% 0.081% 0.079% 0.000% 0.080% 0.079% 0.000% 0.160%	10:52S 10:53S 10:54S 10:54S 10:56S 10:56S 10:56S 10:58S 10:58S	34.0°C 34.0°C 34.0°C 34.0°C 34.0°C	*** TEST I	PASSED *** PASSED *** PASSED *** PASSED *** PASSED ***
Control 3 EC Control 3 IR Ambient Air Blank Control 4 EC Control 4 IR Ambient Air Blank Control 5 EC Control 5 IR		0.000% 0.081% 0.079% 0.000% 0.080% 0.079% 0.000% 0.160% 0.159%	10:52S 10:53S 10:54S 10:54S 10:56S 10:56S 10:56S 10:58S 10:58S 10:58S	34.0°C 34.0°C 34.0°C 34.0°C 34.0°C	*** TEST I	PASSED *** PASSED *** PASSED *** PASSED ***
Control 3 EC Control 3 IR Ambient Air Blank Control 4 EC Control 4 IR Ambient Air Blank Control 5 EC Control 5 IR Ambient Air Blank		0.000% 0.081% 0.079% 0.000% 0.080% 0.079% 0.000% 0.160% 0.159% 0.000%	10:52S 10:53S 10:54S 10:54S 10:56S 10:56S 10:56S 10:58S 10:58S 10:58S 11:00S	34.0°C 34.0°C 34.0°C 34.0°C 34.0°C 34.0°C	*** TEST I	PASSED *** PASSED *** PASSED *** PASSED *** PASSED *** PASSED ***
Control 3 EC Control 3 IR Ambient Air Blank Control 4 EC Control 4 IR Ambient Air Blank Control 5 EC Control 5 IR		0.000% 0.081% 0.079% 0.000% 0.080% 0.079% 0.000% 0.160% 0.159% 0.000% 0.160%	10:52S 10:53S 10:54S 10:54S 10:56S 10:56S 10:56S 10:58S 10:58S 10:58S	34.0°C 34.0°C 34.0°C 34.0°C 34.0°C 34.0°C 34.0°C	*** TEST I *** TEST I *** TEST I *** TEST I *** TEST I *** TEST I	PASSED ***
Control 3 EC Control 3 IR Ambient Air Blank Control 4 EC Control 4 IR Ambient Air Blank Control 5 EC Control 5 IR Ambient Air Blank Control 6 EC		0.000% 0.081% 0.079% 0.000% 0.080% 0.079% 0.000% 0.160% 0.159% 0.000%	10:52S 10:53S 10:54S 10:54S 10:56S 10:56S 10:56S 10:58S 10:58S 10:58S 11:00S	34.0°C 34.0°C 34.0°C 34.0°C 34.0°C 34.0°C	*** TEST I *** TEST I *** TEST I *** TEST I *** TEST I *** TEST I	PASSED *** PASSED *** PASSED *** PASSED *** PASSED *** PASSED ***

All tests within acceptable tolerance.

Coordinator

Last Name: GONCALVES First Name: MICHELLE MI: L

Calibrating Unit New Standard Solution Report

53
5

All tests within acceptable tolerance.

On this date, I installed the above indicated "NEW SOLUTION" in acordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Temperature Probe Serial Number: _

Changed By:

Last Name: GONCALVES


First Name: MICHELLE


Badge No.: 6040

Date:

12/04/2017

MI: L







CHRIS CHRISTIE

KIM GUADAGNO

Lt. Governor

OFFICE OF THE ATTORNEY GENERAL
DEPARTMENT OF LAW AND PUBLIC SAFETY
DIVISION OF STATE POLICE
POST OFFICE BOX 7068
WEST TRENTON, NJ 08628-0068
(609) 882-2000

CHRISTOPHER S. PORRINO
Attorney General

COLONEL JOSEPH R. FUENTES
Superintendent

CERTIFICATION OF ANALYSIS 0.10 PERCENT BREATH ALCOHOL SIMULATOR SOLUTION

ACCEPTANCE SPECIFICATIONS FOR BREATH ALCOHOL SIMULATOR SOLUTION: Ethyl alcohol concentration within, but not exceeding, the range of 0.1174 to 0.1246 grams per 100 milliliters of solution.

MANUFACTURER: Draeger Safety, Inc.

ANALYSIS DATE: 09/21/2017

BREATH ALCOHOL SIMULATOR SOLUTION LOT NUMBER: 17290

Representative samples of the above-referenced Lot Number were tested by Gas Chromatography and found to have a mean ethyl alcohol concentration range of 0.1199 to 0.1220 grams per 100 milliliters of solution.

This lot of breath alcohol simulator solution may be utilized as a known traceable standard for the purpose of conducting periodic tests, pursuant to N.J.A.C. 13:51-4.3, of approved breath test instruments (N.J.A.C. 13:51-3.5) utilized by law enforcement agencies in this State. The manufacturer's expiration date for this lot of breath alcohol simulator solution is <u>September 14, 2019</u>.

As Research Scientist for the Division of State Police, I hereby certify and attest that the tests and results documented in this Certificate of Analysis were performed at the Office of Forensic Sciences of the Division of State Police on properly functioning and calibrated instruments and equipment. All procedures utilized are accurate, objective, and performed on a routine basis by personnel within the Office of Forensic Sciences, in accordance with their professional duties and responsibilities.

Ali M. Alaouie, Ph.D.

Research Scientist

NJSP Office of Forensic Sciences

Sworn to and subscribed before me this 23 day of Septenber , 2017

PETER F MURPHY IV
My Caminission Expires

August), 2019



"An Internationally Accredited Agency"

New Jersey Is An Equal Opportunity Employ or Printed on Recycled Pop wand Recyclable





CHRIS CHRISTIE Governor

KIM GUADAGNO LI. Governor

OFFICE OF THE ATTORNEY GENERAL DEPARTMENT OF LAW AND PUBLIC SAFETY **DIVISION OF STATE POLICE** POST OFFICE BOX 7068 **WEST TRENTON, NJ 08628-0068** (609) 882-2000

CHRISTOPHER S. PORRINO Attorney General

COLONEL JOSEPH R. FLIENTES Superbutendent

CERTIFICATION OF ANALYSIS 0.10 PERCENT BREATH ALCOHOL SIMULATOR SOLUTION

ACCEPTANCE SPECIFICATIONS FOR BREATH ALCOHOL SIMULATOR SOLUTION: Ethyl alcohol concentration within, but not exceeding, the range of 0.1174 to 0.1246 grams per 100 milliliters of solution.

MANUFACTURER: Draeger Safety, Inc.

ANALYSIS DATE: 07/13/2017

BREATH ALCOHOL SIMULATOR SOLUTION LOT NUMBER: 17200

Representative samples of the above-referenced Lot Number were tested by Gas Chromatography and found to have a mean ethyl alcohol concentration range of 0.1208 to 0.1225 grams per 100 milliliters of solution.

This lot of breath alcohol simulator solution may be utilized as a known traceable standard for the purpose of conducting periodic tests. pursuant to N.J.A.C. 13:51-4.3, of approved breath test instruments (N.J.A.C. 13:51-3.5) utilized by law enforcement agencies in this State. The manufacturer's expiration date for this lot of breath alcohol simulator solution is June 28, 2019.

As Forensic Scientist for the Division of State Police, I hereby certify and attest that the tests and results documented in this Certificate of Analysis were performed at the Office of Forensic Sciences of the Division of State Police on properly functioning and calibrated instruments and equipment. All procedures utilized are accurate, objective, and performed on a routine basis by personnel within the Office of Forensic Sciences, in accordance with their professional duties and responsibilities,

> Monica Transontin Forensic Scientist III

NJSP Office of Forensic Sciences

Sworn to and subscribed before me this Lit

MARY ELIZABETH MCLAUGHLIN

ID # 2052190 **NOTARY PUBLIC** STATE OF NEW JERSEY My Commission Expires Dec. 24, 2018



"An Internationally Accredited Agency"

New Juracy Is An Equal Opportunity Employer Printed on Recycled Paper and Recyclable





Calibration complies with ISO/IEC 17025, ANSI/NCSL Z540-1, and 9001



Cert. No.: 4000-8497880

Traceable® Certificate of Calibration for Digital Thermometer

Manufactured for and distributed by: VWR International, LLC, Radnor Corporate Center, Bldg 1, Ste 200, 100 Matsonford Road, Radnor, PA 19087 Instrument Identification:

Model: 61220-601

S/N: 170309355

Manufacturer: Control Company

Standards/Equipment:

Description	Serial Number	Due Date	NIST Traceable Reference
Temperature Calibration Bath TC-231	A79341		
Thermistor Module	A27129	12/01/17	1000401760
Temperature Probe	5267	12/06/17	B6B30059
Temperature Calibration Bath TC-191	A42238		
Thermistor Module	A27129	12/01/17	1000401760
Temperature Probe	5202	12/19/17	B6B30058-1
Temperature Calibration Bath TC-218	A73332		
Thermistor Probe	5356	· 1/10/18	B7104024
Readout, Digital Thermometer	B5C344	3/12/18	B7314035
Temperature Calibration Bath TC-275	B16388		
Thermistor Probe	5357	1/06/18	B7104023
Readout, Digital Thermometer	B5C344	3/12/18	B7314035

Certificate Information:

Technician: 104

Procedure: CAL-06

Cal Date: 4/26/17

Due Date: 4/26/19

Test Conditions:

24.3°C

62.0 %RH 1000 mBar

Calibration Data: (New Instrument)

Unit(s)	Nominal	As Found	In Tol	Nominal	As Left	In Tol	Min	Max	±U	TUR
°C	ĺ	N.A.		0.002	0.001	Y	-0.048	0.052	0.010	>4:1
°C		N.A.		25.000	25.001	Y	24.950	25.050	0.010	>4:1
°C		N.A.		50.001	50.001	Y	49.951	50.051	0.010	>4:1
°C	-	N.A.		100.003	99.999	Υ	99.953	100.053	0.010	>4:1

This instrument was calibrated using instruments Traceable to National Institute of Standards and Technology.

A Test Uncertainty Ratio of at least 4:1 Is maintained unless otherwise stated and Is calculated using the expanded measurement uncertainty. Uncertainty evaluation includes the instrument under test and Is calculated in accordance with the ISO "Guide to the Expression of Uncertainty in Measurement" (GUM). The uncertainty represents an expanded uncertainty using a coverage factor k=2 to approximate a 95% confidence level. In tolerance conditions are based on test results falling within specified limits with no reduction by the uncertainty of the measurement. The results contained herein relate only to the item calibrated. This certificate shall not be reproduced except in full, without written approval of Control Company.

Nominal=Standard's Reading; As Left=Instrument's Reading; In Tol=In Tolerance; Min/Max=Acceptance Range; ±U=Expanded Measurement Uncertainty; TUR=Test Uncertainty Ratio; Accuracy=±(Max-Min)/2; MIn = As Left Nominal(Rounded) - Tolerance; Max = As Left Nominal(Rounded) + Tolerance; Date=MM/DD/YY

Ylund Kodrugues Nicol Rodriguez, Quality Manager

Aaron Judice, Technical Manager

Maintaining Accuracy:

In our opinion once calibrated your Digital Thermometer should maintain its accuracy. There is no exact way to determine how long calibration will be maintained. Digital Thermometers change little, if any at all, but can be affected by aging, temperature, shock, and contamination.

Recalibration:

For factory calibration and re-certification traceable to National Institute of Standards and Technology contact Control Company.

CONTROL COMPANY 12554 Galveston RD Suite B230 Webster TX USA 77598 Phone 281 482-1714 Fax 281 482-9448 service@control3.com www.control3.com

Control Company is an ISO 17025:2005 Calibration Laboratory Accredited by (A2LA) American Association for Laboratory Accreditation, Certificate No. 1750.01.


Control Company Is ISO 9001:2008 Quality Certified by (DNV) Det Norske Veritas, Certificate No. CERT-01805-2006-AQ-HOU-RvA.


International Laboratory Accreditation Cooperation (ILAC) - Multilateral Recognition Arrangement (MRA).

Michelle In Conceives Michelle In Conceives New Jersen State Police CHANGO BARRIED OF BARRIED OF THE WILLIAM TO BARRIED OF THE POLICE OF TH	
ALLERATED STATE OF THE STATE OF	
· · · · · · · · · · · · · · · · · · ·	
DEFARMENT OF THE STATE STATE MICHELLE GONCALVES	
New Jersey State Police Tourse de personne de la life de l'été Coordinator/Instructor	
TWO WORKS AT TEROTORIES AND TWO WATCH	

CENT TENCET

	ORIGINAL COL	IRSE DATES	
	29/17/15	Refresher Course PLACE GCPA GCFA LAXEHURST	instructor working
	6. 7.	a	
-)	
OF	RIGINAL COURS	E DATESRefresher Courses PLACE	INSTRUCTOR
3.			
4. 5.			•
5. 7.			
- 2			
. 8. 9 5	P 2938 (Rov. 02/12)		T





Alcotest 7110 Temperature Probe

CERTIFICATE OF ACCURACY

This is to certify that the Alcotest 7110 Temperature Probe has been tested for accuracy with with instrumentation that is traceable to the National Institute of Standards and Technology (NIST).


The manufacturer recommends accuracy verification of the Temperature Probe within 12 months of the certification date below, or sooner, according to your state's specifications. For accurate temperature readings, the probe value on this certificate, noted below, must

be programmed into the Alcotest 7110.					
Serial Number Temp Probe:	Certification Date:	Next Certification Due:			

XKP2-398

Probe Value:

Draeger, Inc.





CHRIS CHRISTIE Governor

KIM GUADAGNO Lt. Governor

OFFICE OF THE ATTORNEY GENERAL DEPARTMENT OF LAW AND PUBLIC SAFETY **DIVISION OF STATE POLICE** POST OFFICE BOX 7068 **WEST TRENTON, NJ 08628-0068** (609) 882-2000

CHRISTOPHER S. PORRINO Attorney General

COLONEL JOSEPH R. FUENTES SuperIntendent

CERTIFICATION OF ANALYSIS 0.10 PERCENT BREATH ALCOHOL SIMULATOR SOLUTION

ACCEPTANCE SPECIFICATIONS FOR BREATH ALCOHOL SIMULATOR SOLUTION: Ethyl alcohol concentration within, but not exceeding, the range of 0.1174 to 0.1246 grams per 100 milliliters of solution.

MANUFACTURER: Draeger Safety, Inc.

ANALYSIS DATE: 10/19/2016

BREATH ALCOHOL SIMULATOR SOLUTION LOT NUMBER: 16270

Representative samples of the above-referenced Lot Number were tested by Gas Chromatography and found to have a mean ethyl alcohol concentration range of 0.1203 to 0.1220 grams per 100 milliliters of solution.

This lot of breath alcohol simulator solution may be utilized as a known traceable standard for the purpose of conducting periodic tests, pursuant to N.J.A.C. 13:51-4.3, of approved breath test instruments (N.J.A.C. 13:51-3.5) utilized by law enforcement agencies in this State. The manufacturer's expiration date for this lot of breath alcohol simulator solution is October 10, 2018.

As Research Scientist for the Division of State Police, I hereby certify and attest that the tests and results documented in this Certificate of Analysis were performed at the Office of Forensic Sciences of the Division of State Police on properly functioning and calibrated instruments and equipment. All procedures utilized are accurate, objective, and performed on a routine basis by personnel within the Office of Forensic Sciences, in accordance with their professional duties and responsibilities.

> Ali M. Alaouie, Ph.D. Research Scientist

NJSP Office of Forensic Sciences

Sworn to and subscribed before me this 20 day of October , 2016.

NOTARY PUBLIC STATE OF NEW JERSEY

My Commission Expires Dec. 14, 2017



"An Internationally Accredited Agency"

New Jersey Is An Equal Opportunity Employer Printed on Recycled Paper and Recyclable





OFFICE OF TISE ATTORNEY GENERAL DUPARTMENT OF LAW AND PUBLIC SAFETY DIVISION OF STATE POLICE POST OFFICE BOX 7068 WEST TRENTON, NJ 08623-0068 (609) 882-2000

Christopher S. Porrino Attorney General

COLONBL JOSEPH R. FLIENTIES SuperIntendent

CHRIS CHRISTIE Covaniu

KJM GUADAGNO Lt. Clovernor

CERTIFICATION OF ANALYSIS 0.04 PERCENT BREATH ALCOHOL SIMULATOR SOLUTION

ACCEPTANCE SPECIFICATIONS FOR BREATH ALCOHOL SIMULATOR SOLUTION: Ethyl alcohol concentration within, but not exceeding, the range of 0.0469 to 0.0499 grams per 100 milliliters of solution. ANALYSIS DATE: 09/27/2016

MANUFACTURER: Draeger Safety, Inc.

BREATH ALCOHOL SIMULATOR SOLUTION LOT NUMBER: 16230

Representative samples of the above-referenced Lot Number were tested by Gas Chromatography and found to have a mean ethyl alcohol

concentration range of 0.0484 to 0.0492 grams per 100 milliliters of solution. This lot of breath alcohol simulator solution may be utilized as a known traceable standard for the purpose of conducting periodic tests, This for or preath absorber similator solution, may be unitized as a known naccaole standard for the purpose of conducting periodic tests, pursuant to N.J.A.C. 13:51-4.3, of approved breath test instruments (N.J.A.C. 13:51-3.5) utilized by law enforcement agencies in this State. The manufacturer's expiration date for this lot of breath alcohol simulator solution is September 19, 2018.

As Resourch Scientist for the Division of State Police, I hereby certify and attest that the tests and results documented in this Certificate of Analysis were performed at the Office of Forensic Sciences of the Division of State Police on properly functioning and calibrated Analysis were performed at the orthogot Potensie beforees of the Division of state conce on property functioning and canorated instruments and equipment. All procedures utilized are accurate, objective, and performed on a routine basis by personnel within the Office instruments and equipment. All procedures utilized are accurate, objective, and performed on a routine basis by personnel within the Office of Forensic Sciences, in accordance with their professional duties and responsibilities.

Ali M. Alaouic, Ph.D.

Research Scientist

NJSP Office of Forensic Sciences

Sworm to and subscribed before me this 26th day of 20 pt 12 pt 12/2 2016.

MARY ELIZABETH MCLAUGHLIN

ID # 2052190 NOTARY PUBLIC STATE OF NEW JERSEY My Commission Expires Dec. 24, 2018

"An Internationally Accredited Agency"

Near Jersey is An Equal Opportunity Employer Frinted on Recycled Paper and Recyclable





OFFICE OF IT IS ATTORNEY GENERAL DEPARTMENT OF LAW AND PUBLIC SAFETY DIVISION OF STATE POLICE POST OFFICE BOX 7068 WEST TRENTON, NJ 08628-0068 (609) 882-2000

CHRISTOPHER S. PORRINO Altorney General

COLONEL JOSEPH R. FUENTES Superintendent

CHRIS CHRISTIE Governor

KIM GUADAGNO LL Gavernor

CERTIFICATION OF ANALYSIS 0.08 PERCENT BREATH ALCOHOL SIMULATOR SOLUTION

ACCEPTANCE SPECIFICATIONS FOR BREATH ALCOHOL SIMULATOR SOLUTION: Ethyl alcohol concentration within, but not exceeding, the range of 0.0939 to 0.0997 grams per 100 milliliters of solution.

MANUFACTURER: Draeger Safety, Inc.

ANALYSIS DATE: 10/04/2016

BREATH ALCOHOL SIMULATOR SOLUTION LOT NUMBER: 16250

Representative samples of the above-referenced Lot Number were tested by Gas Chromatography and found to have a mean ethyl alcohol concentration range of 0.0965 to 0.0975 grams per 100 milliliters of solution.

This lot of breath alcohol simulator solution may be utilized as a known traceable standard for the purpose of conducting periodic tests, pursuant to N.J.A.C. 13:51-4.3, of approved breath test instruments (N.J.A.C., 13:51-3.5) utilized by law enforcement agencles in this State. The manufacturer's expiration date for this lot of breath alcohol simulator solution is September 27, 2018.

As Research Scientist for the Division of State Police, I hereby certify and attest that the tests and results documented in this Certificate of Analysis were performed at the Office of Forensic Sciences of the Division of State Police on properly functioning and calibrated instruments and equipment. All procedures utilized are accurate, objective, and performed on a routine basis by personnel within the Office of Forensic Sciences, in accordance with their professional duties and responsibilities.

Ali-M. Alnouie, Ph.D.

Research Scientist

NJSP Office of Porensic Sciences

Sworn to and subscribed before me this 5th day of Defoher, 2016.

Notary

MARY ELIZABETH MCLAUGHLIN

ID # 2052190 NOTARY PUBLIC STATE OF NEW JERSEY My Commission Expires Dec. 24

"An Internationally Accredited Agency"

New Jersey Is An Equal Opportunity Employer Printed on Recycled Paper and Recyclable





OFFICE OF THE ATTORNEY GENERAL
DEPARTMENT OF LAW AND PUBLIC SAFETY
DIVISION OF STATE POLICE
POST OFFICE BOX 7068
WEST TRENTON, NJ 08628-0068
(609) 882-2000

CHRISTOPHER S. PORRINO
Attorney General

COLONEL JOSEPH R. FLIGHTES
Superintendent

CHRIS CHRISTIE

Governor

KIM GUADAGNO

CERTIFICATION OF ANALYSIS 0.16 PERCENT BREATH ALCOHOL SIMULATOR SOLUTION

ACCEPTANCE SPECIFICATIONS FOR BREATH ALCOHOL SIMULATOR SOLUTION: Ethyl alcohol concentration within, but not exceeding, the range of 0.1878 to 0.1994 grams per 100 milliliters of solution.

MANUFACTURER: Draeger Safety, Inc.

ANALYSIS DATE: 10/13/2016

BREATH ALCOHOL SIMULATOR SOLUTION LOT NUMBER: 16260

Representative samples of the above-referenced Lot Number were tested by Gas Chromatography and found to have a mean ethyl alcohol concentration range of 0.1928 to 0.1964 grams per 100 milliliters of solution.

This lot of breath alcohol simulator solution may be utilized as a known traceable standard for the purpose of conducting periodic tests, pursuant to N.J.A.C. 13:51-4.3, of approved breath test instruments (N.J.A.C. 13:51-3.5) utilized by law enforcement agencies in this State. The manufacturer's expiration date for this lot of breath alcohol simulator solution is October 3, 2018.

As Research Scientist for the Division of State Police, I hereby certify and attest that the tests and results documented in this Certificate of Analysis were performed at the Office of Forensic Sciences of the Division of State Police on properly functioning and calibrated Instruments and equipment. All procedures utilized are accurate, objective, and performed on a routine basis by personnel within the Office of Forensic Sciences, in accordance with their professional duties and responsibilities.

All M. Alaouie, Ph.D.

Research Scientist

NISP Office of Porensic Sciences

Sworn to and subscribed before me this 17 day of October 2016

Notary

JOHN R LEAVER

ID # 220713B NOTARY PUBLIC STATE OF NEW JERSEY My Commission Expires Dec. 14, 2017

NYA)

"An Internationally Accredited Agency"

New Jersey Is An Equal Opportunity Employer . Printed on Recycled Poper and Recyclobic

